

Battery-Box Premium LV BMU Instruction Manual

V 1.1

VALIDITY

This document is valid for the Battery-Box Premium LV BMU (Battery Management Unit) ("**BMU**") from firmware version 1.0.


INTENDED USE

BMU is applicable for the BYD Battery-Box Premium LV system(s) (LVS 3.8, LVS 7.7, LVS 11.5, LVS 15.4, LVS 19.2, LVS 23.0 and LVL 15.4) (**"Battery-Box"**), and works as a control unit for the system(s).

PRODUCT DESCRIPTION

BMU could launch a WIFI hot pot. Special tools BYD developed could communicate with BMU through the WIFI.

The WFI's name and code are on the label of BMU.



A: RJ45 port for connection with Battery-Box

B: RJ45 port for connection with an inverter

C: Network terminal (Ethernet)

D: Stop button and status LED

Assignment of Port B

	No.	Assignment	
	1	481-A	
12345678	2	481-B	
	3	Unused	
	4	CAN H	
	5	CAN L	
	6	Unused	
	7	Unused	
	8	Unused	



SCOPE OF DELIVERY

- 1×bmu
- 1×Instruction Manual

TECHNICAL DATA

Communication	Ethernet/CAN/RS 485	
Input voltage*	40-60 V	
Input current	200 mA	
Weight	1 kg	
Dimensions (L \times W \times H)	250 mm $ imes$ 122 mm $ imes$ 50 mm	
Ambient temperature in operation	-10 °C	
Relative humidity (non-condensing)	5% to 85%	
Degree of protection (in accordance with IEC 60529	IP21	

*BMU is powered by Battery-Box through the network cable. No other power supply is needed.

LED STATUS

Flashing white and blue alternatively (0.5s white then 0.5s blue): BMU and Battery-Box are initiating.

Glowing white: idle (Battery-Box is neither charging nor discharging).

Flashing white slowly (2s on then 2s off): Battery-Box is charging.


Flashing white quickly (1s on then 1s off): Battery-Box is discharging

Flashing white (1s on then 1s off) and glowing blue: Battery-Box is discharging, and SOC of Battery-Box is below 15%.

Flashing white and blue (1s white once then 1s blue several times): an error has occurred. (1s white once then 1s blue several times are a circle, and also error codes. The definition of the error codes could be read in Battery-Box Premium Operating Manual LVL)

MOUNTING

Install BMU on the wall or a rack. The recommended expansion screw size is M4 \times 12. The minimum distance from the ground is 50 mm.





CONNECTION

- 1. The communication cable between BMU and an inverter cannot be longer than 10 meters. And the cable should be CAT 5 shield or above.
- 2. Please make sure the correct pins are connected between BMU and an inverter.
- 3. The connection between BMU and Battery-Box should be the Straight-Through Wired Cable.

COMMISSIONING

- 1. Make sure an inverter, Battery-Box, and BMU are correctly connected.
- 2. Press the Start Button on Battery-Box.

UPDATING FIRMWARE

The firmware of BMU could only be updated when it operates with Battery-Box. Please refer to the Operating Manual of Battery-Box for further information.

DISPOSAL

Dispose of BMU following the locally applicable disposal regulations for electronic waste.



CONTACT

BYD Glob	al Service					
Mailbox: bboxservice@byd.com		Social media link				
Telephone: +86 755 89888888-47175			https://www.facebook.com/BatteryBoxBYD/			
Address: No.3009,BYD Road, Pingshan,		https://twitter.com/BYD_BatteryBox				
Shenzhen,518118,P.R.China		https://www.linkedin.com/company/byd-batter y				
	www.bydbatterybox.com		,			
Australia	Alps Power Pty Ltd	Europerope	EFT-Systems GmbH	EFT-Systems GmbH		
	Mailbox: service	• •	Mailbox: service@eft-system s/the ilbox: service@eft-syst			
	@alpspower.com.au	@alpspower.com.au		Telephone:		
	Telephone: +61 2 8005 6688 Address: 14/47-51 Lorraine St Peakhurst NSW 221		+49 9352 8523999 +44 (0) 2037695998(UK)			
					+34 91 060 22 67(ES)	
			Website:		+39 02 873683(IT)	
	www.alpspower.com.au		Address: Bruchtannenstraße 28,			
				63801 Kleinostheim, Garmany		
			Website: www.eft-systems.de			
South	SOLARVILLAGE(PTY)LTD USA		EFT USA			
Africa	Mailbox: support		Mailbox:			
	@afriplusenergy.co.za		USservice@eft-systems.de			
	Telephone: + 27 83 3755 486		Telephone: +1(833) 338-8721			
	Address: UNIT 45 DENNEKAMP,		Social media link:			
	SAILSBURY ROAD,		Website: www.eft-systems	s.de/us		
	KENILWORTH, CAPE TOWN,					
	WESTERN CAPE, 7708					

Copyright © BYD Europe B.V. All right is reserved.